

HDMI Firmware Update Guide for Intel® NUC Kit NUC6i7KYK


What this update fixes:

- An issue where surround sound doesn't work with some HDMI 2.0 receivers.


Note	<ul style="list-style-type: none">• An HDMI device MUST be plugged into the Intel NUC for the update tool to work.• Nothing can be plugged into the mini DisplayPort or Thunderbolt™ 3 ports.
-------------	---

To update the HDMI firmware:


1. Download and unzip **HDMI 2.0 Firmware Updater**.
2. Double-click the file **HDMI 2.0 Firmware Updater.exe** to launch the update tool.
3. Click **Agree** on the License Agreement box.
4. The Update Tool detects Intel GPU. Click **OK**.




5. The Update Tool checks that only one HDMI adapter is connected.



6. The Update Tool shows the **Current Firmware Version** and the **Updating Firmware Version**.




7. Click the **Update Firmware** button, then click **OK** on the Warning box.



NOTE: The screen will go black for up to a minute. Do NOT turn off the Intel NUC or the monitor until the update is complete.

8. Click OK on the confirmation box appears when the update is complete.



9. Shut down the Intel NUC and then turn it back on. (A complete shutdown is required; not just a restart of Windows.)

Optional: To confirm that the firmware was updated, follow Steps 2 - 6 above.

